

Nurse call system type

Use on Chair / Seat

Use on Floor

Seat
 1 X HLV301S (seat sensor)
 1 X HJR075 (alarm kit)
 1 X HJM309 (cable)
 1 X HLV006 (Y connector)
 Bed
 1 X HLV301S (mattress sensor)
 1 X HJR075 (alarm kit)
 1 X HJM309 (cable)
 1 X HLV006 (Y connector)
 For seat and bad use parts highlighted in yellow.

Intercall
or
Chub

1 X HJM301 (floor sensor)
 1 X HJM308 (cable)
 Optional
 1 x HLV006 y connector (to allow connection of nurse call button and sensor mat to system)

Seat
 1 X HLV301S (seat sensor)
 1 X HJR075 (alarm kit)
 1 X HJM310 (cable)
 1 X HLV006 (Y connector)
 Bed
 1 X HLV301S (mattress sensor)
 1 X HJR075 (alarm kit)
 1 X HJM310 (cable)
 1 X HLV006 (Y connector)
 For seat and bad use parts highlighted in yellow.
 Quantec product to be used if site fitted with interface module.
 Seat pad QT634
 Mattress sensor QT633

Quantec

Harvest own product
 1 X HJM301 (floor sensor)
 1 X HJM312 (cable)
 Quantec product
 QT644 (floor mat)
 Optional
 1 x HLV006 (y connector) to allow connection of nurse call button and sensor mat to system

Seat
 1 X HLV301S (seat sensor)
 1 X HJR075 (alarm kit)
 1 X HJM309 (cable)
 1 X HJR076 (adapter cable)
 Bed
 1 X HLV301S (mattress sensor)
 1 X HJR075 (alarm kit)
 1 X HJM309 (cable)
 1 X HJR076 (adapter cable)
 For seat and bad use parts highlighted in yellow and add 1 x HLV006 (Y connector)

Aid Call

1 X QT644 floor sensor
 1 X HJR076 adapter

Seat
 1 X HLV301S (seat sensor)
 1 X HJR075 (alarm kit)
 1 X HJM309 (cable)
 1 X HJM002 (adapter cable)
 Bed
 1 X HLV301S (mattress sensor)
 1 X HJR075 (alarm kit)
 1 X HJM309 (cable)
 1 X HJM002 (adapter cable)
 For seat and bad use parts highlighted in yellow and add 1 x HLV006 (Y connector)

Cortney
Thorne

1 X HJM308 floor sensor
 1 X HJM308 cable
 1 X HJM002 adapter

Seat
 1 X HLV301S (seat sensor)
 1 X HJR075 (alarm kit)
 1 X HJM309 (cable)
 1 X HJM356 (adapter cable)
 Bed
 1 X HLV301S (mattress sensor)
 1 X HJR075 (alarm kit)
 1 X HJM309 (cable)
 1 X HJM356 (adapter cable)
 For seat and bad use parts highlighted in yellow and add 1 x HLV006 (Y connector)

Medicare

1 X HJM308 floor sensor
 1 X HJM308 cable
 1 X HJM355 adapter

Highlighted parts are grouped together.

FOR NURSE CALL BUTTONS SEE INFO SHEETS